User & Cleaning Guidelines

High Speed Oven Cavity Liner

1. Best practice is to clean the cavity liner at least every day **at the end of a shift.**
2. In case **fatty food** is cooked inside your high speed oven, operators need to be aware fat can carbonize and self-ignite under repeated influence of high heat and microwaves. In this case cleaning of the cavity **during a shift could be recommended** to avoid the risk of self-ignition.
3. The cavity liner **should not be** placed in a **dishwasher** to enhance the longest life time of the cavity liner it's advised to clean it with mild detergent and a damp cloth. Rinse with water after cleaning and dry off completely. Cleaning in a dishwasher changes the structure of the material.
4. **Do not** use brushes or scrapers in order to not damage the coating.
5. **Avoid contact with** sharp objects and direct heating elements.
6. **Please remember an easy clean liner is an accessory that needs to be replaced every now and then, depending on how you tread it.**

